

# Supported Mobile Phones

September 2009

## **Alcatel**

OT.S853

## **Apple**

iPhone

## **ASUS**

P505

## **Audiovox**

SMT 5600

## **BENQ**

P50

## **BENQ-Siemens**

EF51 Q-Fi  
S68/CL71/EL71

## **BlackBerry**

7100g (Cingular)  
7100i (Nextel)  
7100t/7105t (T-Mobile)  
7130e  
7290  
7520  
8100 (Pearl)  
8300 (Curve)  
8700/8707  
8703 (Verizon)  
8800/8820/8830

## **Cingular / AT&T**

2125  
3125  
8125  
8525  
Tilt (8925)

## **Dopod**

Dopod 535  
Dopod 565

Dopod 585  
Dopod 696  
Dopod 700  
Dopod 810  
Dopod 818  
Dopod 818 pro  
Dopod 838  
Dopod 900  
Dopod s300

### **Eten**

G500  
M600

### **Grundig**

G402i  
M130B

### **HP**

h63xx series  
hw 6515  
hw 6910/6915

### **HTC**

Amadeus  
Blue Angel  
Excalibur  
Herald  
Hurricane  
Magician  
Mteor  
Prophet  
Startrek  
Trinity  
TyTN  
Wizard

### **i-mate**

SP3i  
JAM  
JAMin  
JAQ3  
Jasjam  
Jasjar  
K-Jam  
PDA2K  
Pocket PC  
Smartflip  
Smartphone 2  
SP3  
SP5  
SP5m

**Kyocera**

K323

**LG**

AX490  
CG300  
Chocolate (KG800)  
Fusic (LX550)  
LX150  
Prada (KE850)  
U8210  
U8360  
VX8600  
VX9400

**Mio**

A701

**Motorola**

A1000  
A1200  
A732  
A760/A760i/A768/A768i  
A780  
A910  
A925  
C390  
E1000  
E1070  
E398  
E550/V535/V545/V550  
E680 / E680i  
E770  
E815  
i580  
i605  
i870  
KRZR K1 / K3  
MPX 220  
PEBL U6  
Q  
RAZR V3  
RAZR V3i  
RAZR V3X  
RIZR Z3  
ROKR E1  
SLVR L6  
SLVR L7  
V360  
V500/V501/V525/V600  
V547/ V555 / V551 / V635  
V557

V600i/V620  
V710  
V80

## **NEC**

E616/C616  
L1

## **Nokia**

3230  
3250  
3600/3620/3650/3660  
5500  
6021  
6103  
6111  
6131  
6230 / 6230i  
6255i/6256i  
6260  
6270  
6280  
6310/6310i  
6600  
6630  
6650  
6670  
6680/6681  
6810  
6820  
6822a  
7280  
7370  
7380  
7600  
7610  
7710  
8800  
8910/8910i  
9300/9300i  
9500  
E60  
E61/N61  
E70  
N70  
N71  
N73  
N80  
N90  
N91  
N93  
N-Gage  
N-Gage QD

## **O2**

XDA 2  
XDA Atom  
XDA Exec  
XDA Mini pro  
Xda Neo  
XDAll mini  
XDAlli  
XDAlll  
Xphone  
Xphone2  
Xphone2m

### **PalmOne**

Treo 650  
Treo 700p  
Treo 700w  
Tungsten T3

### **Panasonic**

P341i  
V57  
X11  
X70/X88  
X700 / X701

### **Philips**

Fisio 820/825

### **Qtek**

2020  
2020i  
8010  
8020  
8080  
8100  
8200  
8300  
8310  
8500  
9000  
9090  
9100  
S100  
S200

### **Sagem**

MY 301-x  
MyV76  
MyX6-2  
MYX-8

## **Samsung**

804SS Vodafone  
SGH D500 / D500E  
SGH D510  
SGH D520 / D528  
SGH D600 / D600E / D606 / D608 / P850 / P858  
SGH D720  
SGH D730  
SGH D800  
SGH D820  
SGH D900  
SGH E340  
SGH E360  
SGH E370  
SGH E530/E568  
SGH E620  
SGH E640  
SGH E720  
SGH E730  
SGH E750 / E760  
SGH E770  
SGH E780  
SGH E860v  
SGH E870  
SGH E880  
SGH E900  
SGH E910 / Serene  
SGH I300  
SGH P300  
SGH P900  
SGH S400i  
SGH S410i  
SGH S500i  
SGH T809  
SGH X500  
SGH X670  
SGH X680  
SGH X700  
SGH X800  
SGH X810  
SGH X820  
SGH Z130  
SGH Z140v  
SGH Z300  
SGH Z320i  
SGH Z400  
SGH Z500  
SGH Z510  
SGH Z540  
SGH Zv10  
SGH Zv30

## **Sendo**

X

## **Sharp**

550SH  
703 / 903 / SX13  
GX15 / GX17/ GZ100  
GX25 / GZ200  
GX29  
GX30/GX31/GX32  
TM 200

## **Siemens**

AP75  
CX75  
M75  
S55/S56  
S65/S66  
S75  
SK65/SP65  
SL75  
SX1  
SX66  
SXG75

## **Smart**

Amazing Phone

## **Sony Ericsson**

D750i  
K510i  
K600i / V600i / K608i  
K700  
K750i  
K800i/K790i/K610i/V630/V630i/K618i  
M600i  
P910i  
P990i  
R520  
S700i/S700c/S710  
T606/T608/T610/T616/T618/T630  
T68i/T68  
V800  
W300i  
W550 / W600  
W800  
W810i  
  
W900i  
Z1010  
Z520i  
Z550i  
Z600/Z608  
Z800

## **SPV Orange**

C500  
C550  
C600  
E200  
M1000  
M1500  
M2000  
M3000  
M3100  
M500  
M5000  
M600

### **Téлит**

Neofone

### **T-Mobile**

MDA - Compact  
MDA 2  
MDA Pro  
MDA Vario  
MDA3  
SDA  
SDA Music  
SDA2

### **Toshiba**

803

### **VK Mobile**

VK2010  
VK2020  
VK4000  
VK4500